



# Lorex LW2742 Back Panel Replacement

To remove the Back Panel of your Lorex LW 2742 security system. Prerequisite guide only.

Written By: Alex Kusmierz





## TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Back Panel



- Remove the battery cover on the back of the LCD monitor by unscrewing one 5mm Phillips #1 screw.
- Slide the battery out of the housing. Lightly tap the opposite end of the monitor if the battery does not come right out.

## Step 2



- Remove the four 6mm Phillips #1 screws on the back of the LCD monitor.

## Step 3



- Using a plastic opening tool, gently separate the back panel from the front panel, working the tool around the panel to disconnect it.
  - Carefully remove the back panel
- ⚠ The speaker wire is connected to the motherboard so DO NOT rip back panel away from the monitor.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 07:53:57 AM.